
AC Tubular Motor with Zigbee User Manual



02 Caution!

1. The power supply is AC supply.

2.Please confirm the rated voltage and frequency according to the nameplate when using it. 3. The motor will jog in operation, please do not proceed to the next step until it complete. 4.During operation, the effective interval of the transmitter button operation is 10 seconds. If there is no effective transmitter operation for more than 10 seconds, it will automatically exit the current mode.

5.The motor can be paired with max 10 controllers.

6.Upper&Lower limits cannot be set at the same position, limits saved even power off. 7. The motor runs constantly for at 6 mins max without any other operation.


8.Do not lift the motor by grabbing the wire or antenna.

03 Instructions


Motor head button (H) functions

Functions	Operation	Jogging time	LED lamp flickers	Note
Control the UP/STOP/ DOWN of the Shade	Short press	/	/	Can only operate after the limits are set
Adding/Removing Controller	Hold for 2s	Jog*1	Flicker*1	Operation needs be done within 10s
Zigbee Connecting	Hold for 6s	Jog*2	Flicker*2	Entering Zigbee connection mode
Direction Reverse	Hold for 10s	Jog*3	Flicker*3	All settings saved after direction reversed
Reset	Hold for 16s	Jog*4	Flicker*4	All settings deleted


a.Pairing Motor with Controlle



Way 2: After motor is powered on for more than 10s



Way 3: Power on, add controller B via pre-existing controller A








If the limits are not set, and direction goes opposite.





If limits are set and direction goes opposite














Note: Upper&Lower limits cannot be set at the same point. Before limits set, the motor will run in one-touch mode by pressing Up or Down, hold Up or Down for 2s, motor runs in constant-touch mode.


Once limits set, press Up or Down, motor runs in constant-touch mode.

d.One-touch/Constant-touch Mode

Constant-touch ----->One-touch



Same operation can toggle from one-touch to constant -touch mode. Note: When motor in one-touch mode, hold Up or Down for more than 2s, it will run in constant-touch mode.



f.Hot key to the Fav. Position

Fav

Fast get to the Fav. point


Note: The Fav. position setting only can be done after upper&lower limits set.


Limits cancelled

Note: It is forbidden to run the motor if installed into the shade without limits. Limits should be set immediately to protect the shade.

Note: Do reverse the direction when it goes opposite.

c.Upper&Lower Limits Settin











H button x2s





existing A Controller B removed Remove all controllers:















Remove a single controller

H button



Remove controller B via pre-existing controller A





All controllers removed

Note: All the settings are saved even controllers removed(limits set are saved). Controller A/B are already paired to motor.

04 Zigbee Connecting

*Connection requirement

Make sure the Wi-Fi module and smart phone be connected to the same Wi-Fi network. The smart phone needs to connect to Wi-Fi network and turn on the Bluetooth function first

a.Search for "Smart Life" in the app store or scan the QR code

b.Complete account registration and login to the app




2 Add Device

a.Make sure the phone is connected to the Wi-Fi network b.Make sure the Tuya Zigbee gateway device is connected to "Smart Life" App c.Make the motor is ready to be connected to Zigbee by following steps:






Zigbee connecting





Blue LED flicker

d.Find the added Tuya Zigbee gateway on the "Smart Life" App, click "+" to add a sub-device, and then click "LED already blink", the APP will automatically search for motor device






-Q-

Jiecang ~

.

Wired Zigbee gateway Uving Room



e.After adding successfully, click " / " to modify the device name

Added. Smart Roller Shade 🖉 Device added successfully Add subdevice



The motor start slowly


The motor

The motor strange noi

f.After the motor device is added successfully, the LED on motor head will be on for 10s and then go off.



g.Now the motor can be controlled by App from anywhere, anytime



05 Troubleshooting

Fault	Cause	Solution	
r does not run or ly	1.Low voltage 2.Wrong wire connection 3.Overloading 4.Wrong installation	 Adjust the voltage to rated data Correct the wire connection Put the suitable weight for roller shade Reinstall the tubular motor 	
r suddenly stop	The motr has exceeded termal overheat protection (4 minutes)	Wait for the motor to cool down for approximately 20 minutes	
r makes a oise when it runs	1.The crown and drive adapter are not well adapterd to tube 2.The driving tube is too long, cused the brackets are too tightly	 Change correct size crown and drive adapter If idler is active, make driving tube shorter to avoid the tight status 	